

IRS POWER CONTROLLER FOR IR. OVENS

IRS10 and IRS12

TECHNICAL MANUAL V 4.1

**OLICORP**

Montbrillant 26
CH-1201 Geneva
Switzerland

Phone: +41 22 309 15 40

Local support is available Worldwide
Check on www.olicorp.ch

CE relevant European directives	5
Low Voltage compliance	5
EMC compliance	5
CE Label.....	5
CSA / CUS® Marking	5
Profibus® standard compliance	5
Safety and security aspects	6
Symbols :	6
Safety:	6
PART 1 : DISCOVERING THE IRS	7
What is the IRS system ?	8
The IRS is the top of the art solution to control power on IR ovens.....	8
How do the IRS systems compare to existing solutions ?	9
Totally integrated solution :	9
Closed loop regulation for power regulation (V_{RMS}^2 / R_{Lamps})	9
On-line Load fault detection :	9
Load impedance on-line monitoring and recording :	9
Multi-channels :	9
Integrated electronic protection :	9
Power supply monitoring :	9
Scalability and modularity :	9
Profibus-DP Communications :	9
Multiple regulation algorithms :	9
Hardware and software versions	11
IRS10 versions :	11
List of firmware versions according to the model and usage :	12
Software architecture :	13
PC based software :	14
PLC Program :	14
PART 2 : IRS SYSTEM FEATURES.....	15
Cabling and lamps strategy :	16
IRS Absolute maximum ratings :	16
REGULATION MODES :	17
Phase angle regulation	17
Zero crossing and advanced single cycle regulation	18
Conclusion :	19
Integrated WARM-UP ramps :	20
Shortcuts and overloads :	21
Overload message	21
CutOut message :	21
Resistance measurement, closed loop regulation and dead lamps detection.	22
Why do we need to measure the resistance ?	22
What is done by the IRS ?	22
EMC compliance	23
Harmonics and Flicker standards.	23
Harmonics :	23
Flickering :	24
Running conditions and cooling :	25
Performances :	25
Rth :	25
Maximum internal temperature	26
Running conditions.....	26
PART 3 : USING THE IRS IN 6 STEPS	27

Step 0 : Machine cabling :	28
Step 1 : Product Identification :	29
Step 2 : Mechanical mounting :	30
Mechanical configuration of the IRS for integration into machines :	30
Step 3 : Electrical connections :	32
AC Power supply :	32
Connection to the Oven :	32
DC Power supply and Profibus terminators – W7.X MODELS.	34
DC Power supply and Profibus terminators – W1.X and W2.X MODELS.	34
Profibus termination:	35
Profibus ID:	35
Selecting the Overload protection mode :	35
Step 4: Checking the IRS configuration.	37
Procedure:	37
List of firmware versions according to the model and usage :	38
Step 5: Automation strategy for 20.X Programs – WO.13.x / WO.7.x / WO.20.x SIDEL mode.	39
System calibration	39
Starting the regulation	39
Treating the information back from the IRS	39
Stopping the regulation	39
System Shutdown	39
Exceptions	40
Step 5 : Automation strategy for 5.X Programs – WO.1.x / WO.2.x / WO20.x	41
System configuration	41
System initialisation at start-up	41
Starting the regulation	42
Treating the information back from the IRS	42
System Shutdown	42
Exceptions	42
PART 4 : TECHNICAL COMPLEMENTS	44
RS232 connection : Firmware update and IRS serial control	45
Overview :	45
Hardware connection :	45
Installing the software :	45
Configuring the software :	45
Using the software :	46
Firmware update :	47
Calibration :	47
To ensure a good process quality the IRS calibration have to be check	47
Voltage calibration :	48
Use a calibrate VRMS Voltmeter	48
Measure the voltage between the two phases inside the IRS	48
Enter the value and tick “Calibrate voltage”	48
Vrms read and Vrms expected must be the same	48
Current calibration :	49
Profibus DP : For PROGRAMS 5.X	50
Overview	50
Procedure to use a IRS regulator with a PLC :	50
Protocol description and datagram format :	51
Summary : Basic steps to start the regulation (STD12 protocol) :	54
Profibus DP: For Programs 20.X	55
Overview	55
Procedure to use a IRS regulator with a PLC:	55
Protocol description and datagram format:	57
Summary: Basic steps to start the regulation:	57
LEDs	58

CE relevant European directives

Low Voltage compliance

The IRS products carry the CE mark in compliance with the essential requirements of the European Low Voltage Directive 73/23/EEC of 19/2/73, amended by the directive 93/68/EEC of 22/7/93.

The IRS products installed and used in compliance with the procedures described in the present document meet the essential requirements of the European Low Voltage Directive.

EMC compliance

The IRS products are compliant with the EMC requirements with respect to the European directives 89-336/EEC of the 05//03/89 amended by the 91-263/EEC, 92-31/EEC, 93-68/EEC, 93-97/EEC. The enforcement of this directive is done by standards: EN60204, EN50081-2 and EN50081-3

EM compliance has been certified by an approved EMC testing laboratory. Certificates are available upon request.

More details about EM compliance are given later in this document.

CE Label

By fulfilling the requirements of the Low voltage and EMC regulations, the IRS products are compliant with the CE directives.

CSA / CUS® Marking

The IRS products CSA/UL compliance has been investigated by the CSA laboratories in Toronto, Canada. (May 2007). File number 1871799.

Profibus® standard compliance

The IRS carries the Profibus-DP compliance label and is listed by the PNO organization under reference IRPC1012 with id number 0594Hex.

Safety and security aspects

Symbols :



This symbol means that failure to take note of the information given in this manual may have serious consequences for the safety of the personnel or may result in electrocution.



This symbol means that failure to take note of the information given in this manual may have serious consequences for the installation, lead to incorrect operation of the product, or may damage the product.

Safety:



The installation, configuration, commissioning and maintenance of the IRS products must only be carried out by personnel qualified and trained to work with low voltage electrical equipment in an industrial environment.



The front door should not be opened except by competent technicians when connecting or disconnecting the device. Electrical isolation must be ensured between the equipment and the power supply.



In both off and on modes, the IRS regulator doesn't ensure isolation from the power supply. One should pay attention to the fact that electrical shock may occur when touching the lamps or the cables coming from the IRS. It is thus recommended to turn off the power supply (400 V) within 2 sec following the end of regulation.

PART 1 : DISCOVERING THE IRS

What is the IRS system ?

The IRS is the top of the art solution to control power on IR ovens.

The IRS system aims to control up to 12 InfraRed lamps. Its modular design turns to be optimised for the control of IR ovens on blow molding machines.

The IRS is designed a IP65 cabinet that can be mounted in the machine nearby the oven.

The IRS replaces the successful PWR system that has been widely used on blow moulding machines since 2002. More than 25'000 PWRs and IRSs actually run around the world.

Two models are available:

The IRS10

- 10 channels
- Single phase input + ground (185- 530 VAC 50 / 60 Hz)
- I Max Total : 65 A
- I Max / channel : 7.5 A RMS

The IRS12

- 12 channels
- Single phase input + ground (185- 530 VAC 50 / 60 Hz)
- I Max Total : 75 A
- I Max / channel : 7.5 A RMS

Both models have advanced features :

- Phase angle and advanced single cycle modes (zero crossing)
- Dead Lamps detection and Load Resistance monitoring
- Closed loop regulation (Power regulation based on Voltage and Current)
- Integrated shortcut protection
- Warm-up ramps for tungsten lamps
- Profibus DP communications
- Voltage limitation to protect the lamps
- Online Lamps resistance measurement
- Power supply quality monitoring
- Monitoring and recording of power supply variations.

Installation is simplified by the means of :

- Fast connecting terminators
- 3 points fixation

How do the IRS systems compare to existing solutions ?

Totally integrated solution :

The IRS system is a complete power cabinet by itself. It includes the regulation controller, the power regulation stage (thyristors), and an integrated overload protection, all integrated in an IP65 cabinet.

This concept makes it easy to connect and to mount. Maintenance is also greatly facilitated by suppressing complex electrical cabinets by small plug and play single units.

Closed loop regulation for power regulation (V_{RMS}^2 / R_{Lamps})

By measuring the current and the voltage as well, it is possible to know the exact power sent to the resistive loads. Doing this will avoid any power fluctuations due to the resistance spread or to the power supply irregularity .

On-line Load fault detection :

By measuring the load resistance and the system is able to detect load faults. This point is especially important for the blow moulding machines with a large number of lamps.

Load impedance on-line monitoring and recording :

The system is able to record the changes in the lamps resistance. This information may be used to survey the aging of the lamp.

Multi-channels :

The IRS controls up to 12 channels.

Integrated electronic protection :

A fast electronic breaker is included in the IRS cabinets to protect the electronic components and the lamps.

Power supply monitoring :

In the 2008 version of the IRS, the electrical characteristics of the power supply are monitored to record the variations on the Voltage and current, to detect transient signals and abnormal events.

Scalability and modularity :


The IRS system is designed to be mount directly onto the machine nearby the oven. This concept is thus highly modular...

Profibus-DP Communications :

The IRS modules are certified Profibus-DP slaves and can both receive settings and send alerts from/to the PLCs connected to this field-bus.

Multiple regulation algorithms :

The IRS system currently supports phase angle, zero crossing and advanced single cycle.



IRS brings a total control on the heating process

- Power and voltage regulation
- Closed loop on supply voltage
- Closed loop on lamps resistance
- Lamps controlled individually
- Lamps resistance monitoring
- logging of changes in the lamps resistance to ease the determination of their lifetime.
- Fast detection of dead lamps
- deterministic overload protection
- Running from 185 up to 530 VAC
- Possibility to use low voltage lamps on higher voltage supplies.
- Over-voltage protection
- Data logging, monitoring, consumption follow up
- harmonics suppressor

Hardware and software versions

IRS10 versions :

From 12.2009, ALL former 10 channels models will be replaced by the WO20.X version.

PWR24B WO20.X Software V5.X

PWRSDL WO20.X Software V20.X

IRS10 STD WO20.X Software V5.X

IRS10 SDL WO20.X Software V20.x


Features	WO 1.9	WO 7.10/13.2	WO 2.1	WO 20.x
	STD	SIDEL	STD	SIDEL and STD Universal model Can also replace PWR-SDL
Release date	Mar 2009	Mar 2009	Mar 2009	10 2009
Firmware	V5.18	V20.16	V5.18	V5.18 or V20.16
I _{supply} (A)	70	70	70	70
I _{max-thy} (A)	7.5	7.5	7.5	7.5
N _{channel}	10	10	12	10
V _{supply}	185-530 VAC			
Frequency.	47-63 Hz			
V _{controller}	24 VDC +/- 10%			
I _{controller} (A)	0.25	0.25	0.25	0.25
I _{overload}	200 A			
Additional breaker for back line protection	32A C curve			
Interrupting capacity	6KA			
Running conditions (Non confined)	5-45°C	5-55 °C	5-45°C	5-55°C with T-5°C RMS over 24h, 8-80% HR n.c
Storage	-20-60 °C, 5-95% HR			
Accel.	10G, 11ms, 2 times/s			
Protection	IP65			
Temperature rise inside the cabinet at full power with respect to outside.	22°C	13.5°C	23°C	13.5°C
Power loss	70 W			
Size HxWxD	430X312X188 mm			
Weight	15.4 kg			
Stainless steel	X	X	X	X
Static cooling	X		X	Option

Fan Cooling	Option	X	Option	X
Single hardware configuration for both regulation modes	X	X	X	X
Phase angle	X	X	X	X
Advanced single cycle	X	X	X	X
Adjustable ramps for lamps pre-warming	X	X	X	X
Power regulation $V_{RMS} \times I_{Inst}$	X	X	X	X
Voltage regulation V_{RMS}^2	X	X	X	X
Overload and surge protection	X	X	X	Yes but can be deactivated
Dead lamp detection	X	X	X	X
Temperature survey	X : Turns off the regulation if $T_{inside} > 70^{\circ}C$			
Power supply survey	Yes, and an alarm is sent if the power to the lamp is not reach			
GSD	2.0		2.0	
Min power / lamp	10%	10%	10%	10%
Max power / lamp	Nom	Nom	Nom	Nom
Serial control	X	X	X	X
Update firmware soft	X	X	X	X
Upgrade features soft	X	X	X	X
POWER PLUG	Fast plug terminator – HAN100A from HARTING®			
OVEN PLUG	Fast plug terminator – HAN32 from HARTING®			
24 DC PROFIBUS DP	Ecofast from HARTING			

List of firmware versions according to the model and usage :

Model	Use	Firmware	Hardware
PWR24B	Standard	4.28	12
PWRSDL	SDL	10.54	101
IRS 10	Standard	5.18	20
IRS 10	SDL	20.16	101
IRS 12	Standard	5.18	20

Software architecture :



To ensure the maximal flexibility, the different programs used with the IRS are distributed between :

- The IRS itself to retain recurrent settings or store special algorithms
- The machine's PLC that starts/stops the regulation and sends the desired settings.
- A PC or LapTop that can be used for maintenance purpose

PC based software :**SUPERVISOR :**

This program is used to connect a PC to a single IRS using a serial link. The program is used to test the IRS, to monitor the status of the regulator and to upgrade the firmware.

The IRS intrinsic settings can also be set using this program.

More information is given later in this document and in the SUPERVISOR User's manual

PLC Program :

This program synchronises the regulation (start/stop) with the machine cycle and sends the power settings (Watts) to the IRS according to the users' needs.

Different communication modes are available over profibus-DP, and thus, different PLC programming strategies can be used.

More information is given later in this document.

PART 2 : IRS SYSTEM FEATURES

Cabling and lamps strategy :

It is possible to use the IRS cabinet with several types of lamps and with different cabling topologies.

- The IRS automatically limits the Voltage sent to the lamp according to the type of lamp. It is thus possible to use 400 VAC lamps on 480 VAC supply.
- **The total current regulated by the power cabinet cannot exceed 65A for IRS10 and 75 A for the IRS12.**
- **The total current / channel cannot exceed 7.5 A / channel for both products.**
- **The Overload current is set to 200 A.**



IRS Absolute maximum ratings :

The IRS is accepting input voltage between 185 VAC and 530 VAC, with frequencies ranging between 47 and 63 Hz.

Lamp Nominal Voltage (Vrms)	Power supply Voltage (VAC) +/-10%					
	208	230	400	415	440	480
230	-----	1700	1000	950	900	820
360	-----	-----	2400	2300	2200	2000
400	-----	-----	3000	2900	2700	2500

Green : Maximal power (W) for lamps for a given Power supply voltage and lamp nominal voltage.


The minimal setting per channel is 10% of the nominal power of the lamp in power regulation mode. This limit is set to avoid current bursts with tungsten lamps as the Resistance of the lamp may slightly decrease when running at low power.

REGULATION MODES :

Phase angle regulation

The phase angle regulation relies on a powerful algorithm that monitors both the voltage and the current going through each load and then calculate the power dissipated in these loads. By knowing this exact power, the system is able to evaluate the ratio of the signal which should be removed to reach the targeted power in the lamps. Moreover, this online monitoring of the current and voltage is used to compute the exact resistance of the lamps and then to detect dead lamps.

The phase angle is defined as θ , which is the delay while the circuit must remain opened for each half period. The greater θ is, the less energy remains in the signal.



This method is accurate and one can achieve a precision of less than 0.3%.. The θ angle can be controlled with an accuracy of 1 μ s.

A filter must be integrated into the IRS cabinet for the EMC compliance.

Benefits from phase angle regulation :

- High accuracy
- Almost no variation of the temperature of the filament along the time
- Possibility to run with European and American power supplies indifferently
- Possibility to run with 220, 400 and 480 VAC lamps indifferently
- Possibility to use 220 V lamps onto 400 and 480 supplies and 400 V lamps onto 480 V supplies

Problems related to phase angle regulation :

The main problem related to phase angle regulation is the EMC compliance. For small systems the use of a dedicated EM filter ensures the compliance with EMC standard.

Above 200kW, when using several IRS modules, we have to consider also the machine design. For instance, a machine with poorly shielded cables from the regulators to the ovens may cause pick-up and correlated effects that could spoil the EM characteristics of the machine.

A new type of power stage is actually tested. It uses a microsecond shifting algorithm between the different systems to reduce the correlated effects and ensure a fully E M compliance up to the MW even for poorly shielded machines.

More information is available in the EMC section and in the regulation algorithms section.

Zero crossing and advanced single cycle regulation

In this mode, the regulation is done by removing an entire number of half-periods, evenly distributed onto a 1s period (100 half periods).

The commutation of the thyristors is synchronous with the power to avoid EMC perturbations. The regulation accuracy is over 1%. The lamps may flicker.

Basic description of the algorithm :


The regulation is done using two quantities :

- $P_{1/2 \text{ period}}$: Integrated power during $\frac{1}{2}$ period
- $\Sigma_{100}(P_{\text{period}})$: Energy in the latest 100 periods


Using these two quantities, the number of periods to be removed within the next 100 periods is calculated. The $\Sigma_{100}(P_{\text{period}})$ gives the global number of periods to be removed, while the $P_{1/2 \text{ period}}$ is used to correct low frequencies fluctuation of the input signal.

The removed half period are distributed evenly to smooth the temperature variation of the filament along the time.

IN V SIGNAL (After Signal shaping)



OUT I SIGNAL



Applications :

The accuracy of the advanced single cycle is poor compared to the phase angle regulation. It can hardly be better than 1%.

However this accuracy is good enough for the basic PET process.

The main problems are related to the removal of several successive half periods.

These "holes" are responsible for the flickering effect which occurs because of the lamps' temperature fluctuation over the time. The flickering has a negative effect on the lamps lifetime as well as on the lighting homogeneity.

Removing one ½ period corresponds to a signal shutdown during 10ms in the load. Depending on the lamps geometry the temperature of the load will fall from a few Kelvins, which is enough to cause a small flickering.

It is thus really important to work with lamps adapted to the process. We recommend strongly to choose the lamps with a nominal power close to the expected settings..

Conclusion :

By taking into account these different points it appears that the phase angle regulation which keeps an even filament temperature along the time, is certainly the best alternative for regulation.

But, as the phase angle affects EMC compliance, and induces additional costs related to EMC filtering, it can be necessary to use advanced single cycle instead.

This second way to regulate the power is also efficient when the expected power is close to the lamp's nominal power. But, when the power is decreasing, flickering effects will occur and spoil the spectrum.

We thus suggest to use it to save money and ensure EMC compliance, but we also recommend to adapt the lamps' nominal power with respect to the settings that will be applied to these lamps. The best results will be achieved if the setting remains over 80% of the nominal power.

Integrated WARM-UP ramps :

As a consequence of the cold lamps' low resistance, the current at start-up may rise quickly leading to an overload (> 200 A) if all lamps are turned on simultaneously.

To solve this problem one a warm-up algorithm included in the firmware.

This feature should be configured according to the lamps used in the oven.

In Supervisor program, it is possible to set 2 parameters :

Power : The Power applied to the lamp during the warm up phase

Threshold : Duration of the warm-up expressed in half Sine cycles.

Exemple : 3 KW 400 VAC lamps

Power = 3000 W, Threshold = 200

During 200 half periods (2 seconds at 50Hz) the first lamp will be warmed up with 3000 W. Then it will switch to the desired power with the standard regulation mode (phase angle or adv. single cycle) and it will start to warm the second lamp with 3000 W during 200 half periods....

Shortcuts and overloads :

Overload message

Whenever the total admitted current goes above 200 A, the electronic breaker will turn off.

Before turning the system on again you have to follow this procedure :



- Take care that the power supply is off (no power)
- Check that there is not physical default on the electric circuitry
- Check the state of breakers inside the cabinet, and turn them ON.
- Turn the Power supply on
- Reset the alarm on the IRS by turning the regulation off
- Start regulation again.



- **The system should NOT be reset and restarted automatically ! You MUST check the origin of the problem before starting again the power. If not, you may :**
 - o **Endanger the technicians working around the machine**
 - o **Damage the system by applying to much thermal stress onto the components**
- **We advise to wait at least 1 minute before resetting the system. By doing so, you will avoid any problem related to thermal stress related to the shortcut and thus ensure safe running conditions to you IRS system.**

CutOut message :

The breaker will turn off when more than 32 A is applied to a group of 4 lamps.

Remark : the breaker is C curve breaker. Fast transient states with high current will not turn the breaker off.

Before turning the system on again you have to follow this procedure :



- Take care that the power supply is off (no power)
- Check that there is not physical default on the electric circuitry
- Check the state of breakers inside the cabinet, and turn them ON.
- Turn the Power supply on
- Reset the alarm on the IRS by turning the regulation off
- Start regulation again.



- **You MUST check the origin of the problem before starting again the power. If not, you may :**
 - o **Endanger the technicians working around the machine**
 - o **Damage the system by applying to much thermal stress onto the components**

Resistance measurement, closed loop regulation and dead lamps detection.

Why do we need to measure the resistance ?

As it has been written in previous sections, the lamps resistance is quickly changing according to the temperature of the filament.

This temperature will strongly be related to the RMS voltage applied to the lamp.

For a more accurate process, it is necessary to account for these variation in the regulation.

What is done by the IRS ?

The purpose of the IRS is to regulate power.

The IRS measures continuously both the voltage and the current applied to the different lamps. From this measurement, the IRS calculates the RMS Voltage that should be sent to the lamps with the purpose to control accurately the RMS Power dissipated in the lamps.

From the instantaneous Current and Voltage it is possible to compute the instantaneous value of the resistance for each lamp.

In the standard implementation of the IRS software, this value is transmitted to the Profibus DP, for further monitoring.

It is also possible to use only the nominal resistance of the lamps in the power regulation algorithm. To do so, one has to select the "Use Rnom option" when configuring the IRS internal settings (PC supervisor setting).

EMC compliance


Harmonics and Flicker standards.

As from Jan 1st 2001, compliance with the Harmonics and Flicker standards becomes a mandatory part of the EMC Directive. This applies to all products within the scope of these standards.

For rated currents from 16A to 75A per phase, IEC/EN61000-3-4 applies.

Harmonics :

The Harmonics are generated by brutal changes in the current shape due to circuits closure or opening.




The phase angle regulation mode is highly affected by the harmonics problem, especially when the current is turned on near the top of the phase. A Specific EMC filter must be added to ensure EMC compliance. Contact our technical support center for more information.



But the harmonics may have more subtle causes. For instance, with zero crossing or advanced single cycle, a bad synchronisation of the command with the power supply zero will induce some harmonics.

Even without any error on the localisation of the zero, there could be some harmonics due to the thyristors themselves when they are started with a really low signal level. This effect is really small but could be increased by correlation effects between the different channels.

Bad synchronisation of the zero.



Thyristors oscillation at startup



To suppress these effects we have introduced a highly accurate zero detection algorithm which is able to set the zero with 1 μ s accuracy.

As it, the IRS is EMC compliant with the zero crossing and advanced single cycle algorithms for currents ranging from 16 A to 75 A, even without any filtering stage.

In the future, the thyristors will be replaced by a new type of component that will suppress also the oscillation at startup. By doing that, we will obtain even more better results that will allow us to work with higher currents and to suppress the filtering for zero crossing and advanced single cycle regulation.

Flickering :

The other negative effect that could occur, is the flickering. This effect is different from the "lamp flickering" mentioned earlier in this document. Lamps flickering is the variation of luminance of the lamp due to the alternative cooling and warming of the filament when the current is on or off during zero crossing and in a limited way during advanced single cycle. The present flickering is related to the variation of power supply voltage due to the variation of the load.....

The power regulation affects in several ways the power supply :

- the total load on the supply when lamps are on will affect the supply voltage. This effect depends on the power consumed by the ovens and on the quality (strength) of the supply. This effect is constant along the time and doesn't affect the EM compliance.
- The variation of the load along the time, related to the variation of the power settings, will also affect the supply voltage and introduce some variations related to the change of the settings.. This effect is slow (usually for the PET process the settings are quite even along time) and doesn't affect the EM compliance.
- The regulation itself may affect the supply when many lamps are shut down or started simultaneously in the regulation algorithm.

For instance, in the zero crossing regulation mode, several lamps may be off simultaneously during several periods and induce an effect onto the power supply. Moreover, in this type of regulation the temperature of the filament will have enough time to cool down... With a cooler filament, the resistance will fall quickly , leading to a huge current at the next active period....

The IRS system are already optimised with respect to these problems. First, we propose the advanced single cycle mode that ensures an even distribution of the periods to reduce filament cooling effects. Secondly, our algorithm avoids correlations between the different channels by shifting the off period for each lamp. The total load on the supply is thus quite even.

Running conditions and cooling :

Performances :

Like any electrical device the PWR and IRS systems have power losses. Basically any conductor has a small resistance that contributes to the emission of heat in the system.

With the previous system, the PWR, the losses were around 1% of the nominal power (30 kW) :

$$P(\text{loss PWR}) = 270 \text{ W}$$


The IRS has been highly improved and the loss is now around 0.25% of the nominal power (30kW) :

$$P(\text{loss IRS}) = 70 \text{ W}$$

Rth :

This power contributes to heat the system and must thus be extracted.

Any thermodynamics system is characterized by its thermal resistance Rth.
The Rth gives the temperature rise of an isolated system with respect to the outside when a given energy is released in this system.



$$T_{in} = T_{out} + X \cdot R_{th}$$

Exemple : If $R_{th} = 0.2 \text{ }^{\circ}\text{C/W}$ and the loss in the system is 100 W, then $T_{in} = T_{out} + 20^{\circ}\text{C}$.

The IRS and PWR systems have various Rth according to their mechanical design .

Model	Rth °C/W
PWR	0.08
IRS10 no Fan	0.33
IRS10 Fan	0.19
IRS12 no Fan	0.30

Maximum internal temperature

An other characteristics of the system is the maximum temperature sustainable by the IRS and PWR without any alteration of its performances.

Electronics systems usually run at temperatures ranging from 70 to 85°C for digital electronics and higher for power electronics.

Indeed, the limiting elements in the PWR and IRS are the electromechanical breakers used to protect the cables from the IRS and PWR to the ovens.

In the PWR the limit for the temperature on the breaker is 55°C, while it is 70°C for the breaker used in the IRS.

Running conditions

The Running conditions of the IRS and PWR are directly calculated from the above characteristics :


Model	Power loss At 30 kW	Rth	Temp Rise	Max temp On breaker	Max temp On heatsink	Max outside temp
PWR	270	0.08	21.6	55	60	38.4
IRS10 no Fan	70	0.33	23.1	70	70	46.9
IRS10 Fan	70	0.19	13.3	70	70	56.7
IRS12 no Fan	70	0.30	21	70	70	49

The maximum temperature outside given in the previous table is valid if the mechanical integration of the system in the machine is done in good conditions. By good conditions we mean that the system must be installed in a non confined volume to allow natural convection to occur. If the box is enclosed in a cabinet or a closed volume, some additional test in real conditions should be performed.


PART 3 : USING THE IRS in 6 STEPS

Step 0 : Machine cabling :

The following scheme describes the usual architecture of the electrical supply in the machine for the IRS.



Advised circuitry and cabling for IRS :



Step 1 : Product Identification :

The product identification is located inside the IRS cabinet on the outer side of the door :

OLICORP 1207 Geneva Switzerland www.olicorp.ch	
IRS 10 Serial : _____ Date : _____ Software Version : _____ Power controller for IR ovens Single Phase 360-500 VAC, 65 A 47-63Hz 10 channels with max 7.5 A / channel	
WARNING : MORE THAN ONE LIVE CIRCUIT, See Diagram AVERTISSEMENT : CET EQUIPEMENT RENFERME PLUSIEURS CIRCUITS SOUS TENSION, Voir le schéma WARNING: SEPARATE OVERCURRENT PROTECTIONS IS REQUIRED TO BE PROVIDED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODES. AVERTISSEMENT: LE CIRCUIT DOIT ETRE MUNI D'UNE PROTECTION DISTINCTE CONTRE LES SURINTENSITES CONFORMEMENT AU CODE NATIONAL DE L'ELECTRICITE	


Serial number of the IRS and manufacturing date. Necessary for any technical support contact

Factory firmware version. May have been upgraded by the customer.


Step 2 : Mechanical mounting :

Mechanical configuration of the IRS for integration into machines :



The following diagram describes the IRS mechanical design.



Dimensions. Please note that IGES model is available from our Website.



Attention : The IRS system must be installed in a non confined place so that natural convection will ensure a sufficient cooling of the system.



Step 3 : Electrical connections :

AC Power supply :

The IRS modules are single phase devices. They sustain up to 96 amps under 185-530 VAC 47-63 Hz.

The IRS terminators are compatible with HARTING® HANAXIAL 100A terminators.



If you need to purchase directly the terminators, please use the following BOM :

http://www.olicorp.ch/support/pdf/bom_harting.pdf

Available from HARTING AG. www.harting.com

Connection to the Oven :

The IRS modules are using HAN32 terminator from HARTING.


If you need to purchase directly the terminators, please use the following BOM :

http://www.olicorp.ch/support/pdf/bom_harting.pdf

Available from HARTING AG. www.harting.com


The Pin connection is done as follow .

Lamp	1	2	3	4	5	6	7	8	9	10	11	12
In	1	2	3	4	5	6	7	8	9	10	11	12
Out	24	25	26	27	28	29	30	31	32	17	18	19




DC Power supply and Profibus terminators – W7.X MODELS.

The 24 VDC, 220-350 mA power supply and the Profibus connection come all in a single Harting® terminator. Each IRS has 2 connectors, one for input, the second to chain to the next device.



If you need to purchase directly the terminators, please use the following BOM :
http://www.olicorp.ch/support/pdf/bom_harting.pdf
 Available from HARTING AG. www.harting.com

DC Power supply and Profibus terminators – W1.X and W2.X MODELS.




The 24DC is connected to the IRS using a HAN3 terminator.


The Profibus DP is connected directly onto the control board inside the cabinet. 2 feedthrough are set to accept the in and out cable from profibus.
 Next sections shows how to connect the red and green cable to the board.

Profibus termination:

Depending on the position of the IRS slave on the bus, you will have to set the two jumpers, as shown on the following diagram, to terminate the bus using the right impedance. In that case, the wires between the MPU and the remaining unused connector should be unplugged.



The Jumpers are set – The bus is terminated



The Jumpers are not set – The bus is not terminated

As an alternative, a bus terminator can be plugged outside of the cabinet. In that case, the wires may stay plugged, but the jumpers on the MPU shouldn't be set.

Profibus ID:

The Profibus ID is set using the two wheels on the left of the MPU:


The PROFIBUS_DP address is displayed in a hexadecimal format.

$$PFBaddr = (SW1value * 16) + SW2value$$

Example:

$$PFBaddr = (1 * 16) + 5$$

$$PFBaddr = 21$$




The addresses between 1 and 125 are available for the slaves.

NOTE: The address is read during the boot. So, after change to the Profibus address, one has to turn off/on the 24 DC supply before using it.

Selecting the Overload protection mode :

For version WO20 and above, the integrated overload and shortcut protection module can be deactivated. This deactivation may be necessary when the EMC compliance of the electrical supply in the factory running the blow molding machine can not be achieved and when EMC filters can not be installed on the machine. In this case the overload detection system can be affected or biased by external perturbations and must be deactivated.


The consequence of the deactivation is that the IRS will not be fully protected against shortcuts and might be damaged by such events.



Step 4: Checking the IRS configuration.

To do so, one has to install the latest version of the SUPERVISOR program onto a PC (windows 95-XP) and connect to the IRS using a null modem cable.

The SUPERVISOR is available in the support section of our web site: <http://www.olicorp.ch>




DB9 connector for the RS232 connection


Procedure:

- 1) Start the SUPERVISOR program
- 2) Connect a null modem cable to the IRS
- 3) Turn the 24VDC on

On the IRS, the LEDs 2 and 4 must be ON.



On the SUPERVISOR, The “informative Icons” should appear on the lower right of the window.



Check that the IRS is well connected and that the firmware version is the right one.

List of firmware versions according to the model and usage :

Model	Use	Firmware	Hardware
PWR24B	Standard	4.28	12
PWRSDL	SDL	10.54	101
IRS 10	Standard	5.18	20
IRS 10	SDL	20.16	101
IRS 12	Standard	5.18	20

See : SUPERVISOR User’s manual for information about firmware upgrade and product configuration.

Step 5: Automation strategy for 20.X Programs – WO.13.x / WO.7.x / WO.20.x SIDEL mode.

The automation strategy describes the different possible solutions to control the power system with the PLC:

- Starting the regulation (oven on/off)
- Sending the power settings for the oven
- Treating the data from the IRS (alarms).

System calibration

The calibration is done by OLICORP at factory.

Starting the regulation

To start the regulation, the PLC has to send:

- The desired power (% of nominal power) applied for each lamp: Pe (%)
- The start/stop command (Which should be set to “Start”, of course)

Treating the information back from the IRS

The PLC has to treat the information coming back from the IRS:

- The supply Voltage: SV (Volts)
- The alarms:
 - § Overload
 - § Cutout
 - § Overheat
 - § Sector default
- The lamps states (Broken or not) for the ones that are ON.

Stopping the regulation


To stop the regulation, the PLC has to send:

- The start/stop command (Which should be set to “Stop”, of course)

System Shutdown

The main supply must be switched off first. Otherwise, this step doesn't require any specific action.

Exceptions

		Exception	Effects
Software treatment of the exception	An alarm is emitted The regulation can be stopped	Critical sector default $V_{\text{supply}} < 320 \text{ V}$	The regulation stops, An alarm is sent to the Master. The system needs a software reset to restart (regulation off and then on again)
		Sector Default: $V_{\text{supply}} < 360 \text{ V}$	An alarm is sent to the PLC.
		Dead lamp	An alarm is sent to the Master. The regulation is stopped on this channel.
		Overload $I > 200 \text{ A}$	The regulation stops. An alarm is sent to the Master. The system needs a software reset to restart (regulation off and then on)
		Temperature to high	The regulation stops. An alarm is sent to the Master.
	No alarm	Profibus down	The regulation is stopped and will start again when the Profibus DP will be back.
		24 VDC down	Should never happen when main supply is on. The regulation stops.
	PLC failure	If the Profibus watchdog is not affected, the IRS cannot see it. The regulation goes on.	
	24 VDC starts after the HV supply	Should never happen. Non-deterministic. It can damage the electronics.	
	The current in one channel is higher than 10 A continuously but the total current remains below 200 A	We cannot detect that. After a while the related thyristor will be damaged.	

Step 5 : Automation strategy for 5.X Programs – WO.1.x / WO.2.x / WO20.x

The automation strategy describes the different possible solutions to control the power system with the PLC :


- Starting the regulation (oven on/off)
- Sending the power settings for the oven
- Treating the data from the IRS (alarms, measured resistances....)

System configuration

Before doing anything with the IRS regulator, it will be necessary to configure the basic functions of the device :

- Regulation mode : Phase angle, advanced single cycle
- Ramps : Validation of the integrated ramping function to warm the lamps
- Turning on or off the resistance measurement
- Voltage and current calibration
- *Optional* : Preseting the regulation parameters (lamps service voltage, lamps nominal power)

This configuration is either done by OLICORP at factory according to users' specifications, or can be done while mounting the IRS using the serial bus connexion and the SUPERVISOR program.



The system configuration MUST be done from the PC using the SUPERVISOR or OLPWR24COM programs

The Other steps can be done either from the PLC or from the PC

System initialisation at start-up

If not done during initial system configuration, at system start-up the basic parameters used by the regulator must be sent by the PLC (or PC) to the IRS

These parameters are :

- the lamps service voltage : SRVV (Volts)
- the lamps nominal power : MaxP (Watts)

they are related to the basic configuration of the oven

This step can be avoided, if one stores these values directly on the control board. The SUPERVISOR software, used to configure the settings of the IRS, has an option to set SRVV and MaxP in the ROM memory of the IRS.

If this option is used, it is even possible to select a simplified Profibus DP protocole (IRSPWR_STD_SHORT instead of IRSPWR_STD) to ease the programming of the PLC by suppressing the parameters SRVV and MaxP in the Profibus Protocole.

More about that in the ProfibusDP section.

Starting the regulation

To start the regulation, the PLC has to send :

- the desired power for each lamp : PW (Watts)
- the start/stop command

Treating the information back from the IRS


The PLC has to treat the information coming back from the IRS :

- Measured resistances : RM (Ohms)
- The Applied Power : PWE (Watt)
- The supply Voltage : SV (Volts square)
- The alarms :
 - ⌘ Overload
 - ⌘ Overheat
 - ⌘ sector default
 - ⌘ Dead lamp

System Shutdown

This step doesn't require any specific action

Exceptions

		Exception	Effect
Software treatment of the exception	An alarm is emitted The regulation can be stopped	Sector Default : Vsupply < 100V during more than 1 second	The regulation stops, An alarm is sent to the PLC. The system needs a software reset to restart (regulation off and then on)
		Power not reach : Power applied < power expected	The regulation goes on, an alarm is sent to the PLC
		Dead lamp	The regulation goes on, an alarm is sent to the PLC
		OverLoad I > 200 A	The regulation stops. An alarm is sent to the PLC. The system needs a software reset to restart (regulation off and then on)
		Temperature to high	The regulation stops. An alarm is sent to the PLC
	No alarm	Profibus down	The regulation is stopped and will start again when the Profibus DP will be back
		24 VDC down	Should never happen when main supply is on. The regulation stops.
No treat		PLC failure	If the Profibus watch dog is not affected, the IRS can not see it. The regulation goes on.

	24 VDC starts after the HV supply	Should never happen. Non deterministic. It can damage the electronics.
	The current in one channel is higher than 7.5 A continuously but the total current remains below 200 A	We can not detect that. After a while the thyristor will be damaged.

(1) Available only with fw2.45 and >. Prior to this firmware the regulation was stopped...

Part 4 : Technical complements

RS232 connection : Firmware update and IRS serial control

Overview :

The RS232 connection is used for maintenance purpose.

To use the RS232 connection, **you need a null-modem cable** with an RS232, DB9 male connector on the IRS side and the OL-PWR24COM program.


While connected it will be possible to :

- control the regulation for test purpose
- upload/download the firmware
- set the IRS main parameters

Hardware connection :



When connecting the computer to the IRS module through the serial link, you have to pay attention to have both devices wired to the same ground to avoid any electrical discharge that could damage either device.



RS232 DB9
connector

To connect the cable you have to open the cabinet and then to plug to the female connector onto the MPU card. Pay attention to push softly when you plug the connector.

If necessary, the cable can be connected/disconnected while the MPU is on (24 VDC on).

Installing the software :

The SUPERVISOR is available from our Website.


Once unzipped, run the setup.exe program to install it onto your Windows system.

Configuring the software :

There is only one thing to configure. You have to choose in the option Com Port menu the COM Port which connects the PC to the IRS.

Using the software :

The SUPERVISOR interface looks like the following figure :



The connection status is summarized on the lower right part of the window. Once started the program tries to connect to the IRS... It takes a few seconds to connect.

The program has two modes (mode menu):

- The monitor mode
- The control mode

The monitor mode is used to monitor the settings of the IRS. This function can be used once or in a repetitive way (pooling)...

In this mode, the program returns the power applied to each lamp (PWE), the resistance measured for each lamp (RM), the service voltage set for each lamp (SRVV), the nominal power set for each lamp (MAXP), the status of the oven (On/off), the measured supply voltage (SV).

In the control mode, it is possible to control the regulation by sending the different settings to the IRS (SRVV, MAXP, PW, run on/off).


Beside these standard uses, the program is also used to configure the IRS or to get factory information (menu tools hardware information) :


Read only :

- Hardware version
- MainMaxVolts and MainMaxamps are constants used to tune the IRS
- ID : Serial number

Read/Write :



- Current configuration for the regulation mode and of the lamps pre-warming (ramps).





Firmware update :

The latest versions of the firmware are available on our web site from the download section. From the update window you can select the desired firmware (.olc file) and transfer it to the IRS. It takes about 10 sec to transfer the olc file to the IRS. The IRS must be rebooted once the installation is finished.




Calibration :

To ensure a good process quality the IRS calibration have to be check

Voltage calibration :

Use a calibrate VRMS Voltmeter
Measure the voltage between the two phases inside the IRS
Enter the value and tick "Calibrate voltage"
Vrms read and Vrms expected must be the same

enter the
value



Calibration Interface

Vrms read by IRS / PWR: 388

Vrms Expected : 400

Calibrate Voltage

Procedure : Turn main power on. Use the Calibrate Voltage button to calibrate the voltage according to the supplied voltage (Vrms expected).
CrtMMV : 817

I Offset : 0 mA Expected 0 mA

I Inst. : 0 mA Expected 0 mA

Theoretical value of Offset when no load : (I Offset + I Inst) 0

Set Offset (No current in Sensor)

Calibrate Current

Step 1 : Turn power on. Oven Off. Tune the Offset to get I Inst = 0 +/- 10 mA. (I Inst = I Read - I Offset)

Step 2 : Turn power and 24DC off. Replace black and green wires on CN1 by a 10k resistor. Current should be set at 3000 mA. If using 5 k, current will be 6000 mA. Turn 24 DC and then Power on. Do current calibration

Close

Current calibration :

Calibration Interface

Vrms read by IRS / PWR: 403
 Vrms Expected: 400
 Calibrate Voltage

Procedure : Turn main power on. Use the Calibrate Voltage button to calibrate the voltage according to the supplied voltage (Vrms expected).
 CrtMMV : 844

I Offset: 0 mA Expected: 0 mA
 I Inst: 2996 mA Expected: 3000 mA
 Theoretical value of Offset when no load: 2996
 (I Offset + I Inst)

Set Offset (No current in Sensor)
 Calibrate Current


Step 1 : Turn power on. Oven Off. Tune the Offset to get I Inst = 0 +/- 10 mA. (I Inst = I Read - I Offset)
 Step 2 : Turn power and 24DC off. Replace black and green wires on CN1 by a 10k resistor. Current should be set at 3000 mA. If using 5 k, current will be 6000 mA. Turn 24 DC and then Power on. Do current calibration

Close

1st AC power on, set the I Offset Expected the way is to obtain Iinst = 0

2nd Plug the Current Calibrator and enter the value 3000 in I inst expected then set Calibrate Current

With the current calibrator WO12.1 you have 1% precision



Instead of using the current calibrator you can use a calibrate Arms ampmeter and measure the current through a resistance

Profibus DP : For PROGRAMS 5.X

Overview

The IRS power regulator from OLICORP is a PROFIBUS-DP slave which runs accordingly to the Profibus-DP specifications defined in the standards EN 50170 / DIN 19245 / Part 3.

On this type of network, the MASTER DEVICES control the data communication on the bus while the SLAVES DEVICES only answer the requests from the masters.

The master may be :

A Programmable Logical controller (PLCs)

A PC with a Profibus-DP interface.

The OLICORP IRS module has been successfully tested with several masters:

Siemens PLCs "SIMATIC 400",

Siemens PLCs "SIMATIC 300",

B&R PLCs

Omron CJ1M

SST profibus master card (PC solution) with a windows based user-interface

SST-PFB SLC profibus scanner module for Allen Bradley SLC PLCs.

Procedure to use a IRS regulator with a PLC :

1. Initialisation :

The GSD file provided by OLICORP contains a standardized description of the IRS regulator, which enables the automatic detection of the IRS regulator by the master.

The GSD file, olic0594.gsd from our web site should be used.

Note : The name of the GSD must be olic0594.gsd to work properly. When downloading the latest version of the gsd from our site, please rename it if necessary.

2. incorporate the different slaves in the project.

With the Siemens environment it is simply done by the IRS slave from the slave list to the profibus network in the STEP7 programming interface.

According to the GSD :

The type of the slave is : IRPC12-60

The profibus identification is : 0x0594

Two protocols can be selected :


IRS_PWR_STD12

IRS_PWR_STD12_SHORT

The slave ID is set using the ID wheels on the main MPU board. Turn off/on the 24 DC supply to reload the new address.

At this point, the Profibus-DP network should be initialised and should work correctly.

The master is starting to exchange empty datagrams with the IRS slaves. If this exchange is successful the profibus LED onto the MPU card turns to green.



3. Start communication by sending commands and receiving data to/from the IRS.

Then the communication is done through simple datagram exchanges between the master and the slaves.

See next section.

Protocol description and datagram format :

Configuration datagram

The configuration datagram is built according to the GSD description :

Two type of protocols are available on the IRS and PWR systems:

IRS_PWR_STD12

IRS_PWR_STD12_SHORT

The SHORT version is used to simplify and optimize the exchange by suppressing the information about SRVV and Pmax (2 x 12 words are suppressed in the datagram).

To work with this version, on has to set these values manually with the OLPWR24COM software and to save them in the ROM memory of the IRS during system installation.

IRS_PWR_STD12 - INPUT 5 WORDS – OUTPUT 37 WORDS

0xD4, 0xEC, 0xEB, 0xEB

```

0xD4 = 11010100
      |||||
      |||++++- Data Length 0100 == 5
      |+----- Input (Slave->Master)
      +----- Type = Word
      +----- Coherent check

0xEC = 11101100
      |||||
      |||++++- Longueur données 1011 == 13
      |+----- Output (M->S)
      +----- Unité = Word
      +----- Cohérence sur données complètes
  
```

```
0xEB = 11101011
        |||||
        |||++++- Longueur données 1011 == 12
        ||+----- Output (M->S)
        |+----- Unité = Word
        +----- Cohérence sur données complètes
```

```
0xEB = 11101011
        |||||
        |||++++- Longueur données 1011 == 12
        ||+----- Output (M->S)
        |+----- Unité = Word
        +----- Cohérence sur données complètes
```

IRS_PWR_STD12_SHORT – INPUT 5 WORDS – OUTPUT 13 WORDS

0xD4, 0xE0, 0xEB

```
0xD4 = 11010100
        |||||
        |||++++- Data Length 0100 == 5
        ||+----- Input (Slave->Master)
        |+----- Type = Word
        +----- Coherent check
```

```
0xE0 = 11100000
        |||||
        |||++++- Data Length 0000 == 1
        ||+----- Output (M->S)
        |+----- Type = Word
        +----- Coherent check
```

```
0xEB = 11101011
        |||||
        |||++++- Data Length 1011 == 12
        ||+----- Output (M->S)
        |+----- Type = Word
        +----- Coherent check
```

Input Datagram (S -> M) (5 words)

Command	Reserved.	P not Ok		BL		Sqr(Vrms)			
0	1	2	3	4	5	6	7	8	9

Byte 0 : Command byte content :

bit	Meaning
1	<i>Reserved</i>
10	<i>Reserved</i>
100	<i>Reserved</i>
1000 <i>Read Only</i>	1 = Alarm "Overload" 0 = Normal state.
10000	1 = Regulation ON (ON Command acknowledge) 0 = Regulation OFF
100000 <i>Read Only</i>	1 = Alarm "CutOut" (Breaker) 0 = Normal state.
1000000 <i>Read Only</i>	1 = Alarm "OverHeat" 0 = Normal state
10000000 <i>Read Only</i>	1 = Alarm "SectorDefault" 0 = Normal state.

Byte 2 and 3 : P not Ok byte content :

1 bit per lamp. The bit is turned to 1 when the IRS can not apply the required power to the given lamp. 4 bits reserved.

V1	V2	...	V12	Rs1	...	Rs4
<i>bit0</i>	<i>bit1</i>		11	12		15

Byte 4 and 5 : BL Dead Lamp byte content :

1 bit per lamp. The bit is turned to 1 when the IRS detects a load fault

L1	L2	...	L12	Rs1	...	Rs4
<i>bit0</i>	<i>bit1</i>		11	12		15

Byte 6-9 : Sqr(Vrms) byte content :

Square V(rms) read by the IRS. .

Output datagram (M -> S) (37 Word)

WORD 1 . Byte 0 : Command byte content :

bit	Meaning
1	<i>Reserved</i>
10	<i>Reserved</i>
100	<i>Reserved</i>
1000 <i>Read Only</i>	Not used
10000	1 = Regulation ON 0 = Regulation OFF
100000 <i>Read Only</i>	Not used
1000000 <i>Read Only</i>	Not used
10000000 <i>Read Only</i>	Not used

WORD 1. Byte 1 : NOT USED

WORD 2 – WORD 13 : Power expressed in Watts, to be applied to each channel.

WORD 14- 25 : Service voltage of the lamps

WORD 26-37 : Nominal power (W) of the lamps.

In version IRSPWR_STD_SHORT, the words 14-37 are not used.

Summary : Basic steps to start the regulation (STD12 protocol) :

- Set the Service voltage for the loads.
- Set the nominal power for the loads.
- Set the desired power for the loads
- Start the regulation.
- Set the power for other lamps or modify the desired power.

Profibus DP: For Programs 20.X

Overview

The IRS power regulator from OLICORP is a PROFIBUS-DP slave which runs accordingly to the Profibus-DP specifications defined in the standards EN 50170 / DIN 19245 / Part 3. The Profibus-DP certification is pending.

On this type of network, the MASTER DEVICES control the data communication on the bus while the Slaves devices only answer the requests from the masters.

The master may be:

A Programmable Logical controller (PLCs)

A PC with a Profibus-DP interface.

The OLICORP IRS module is a Profibus slave that has been successfully tested with several masters:

Siemens PLCs "*SIMATIC 400*",

Siemens PLCs "*SIMATIC 300*",

SST profibus master card (PC solution) with a windows based user-interface

SST-PFB SLC profibus scanner module for Allen Bradley SLC PLCs.

Procedure to use a IRS regulator with a PLC:

4. Initialisation:

The GSD file provided by OLICORP contains a standardized description of the IRS regulator, which enables the automatic configuration of the IRS regulator by the master.

The GSD file, "olic0594.gsd" from our web site should be used.

Note: The name of the GSD must be "olic0594.gsd" to work properly. When downloading the latest version of the GSD from our site, please rename it if necessary.

5. Incorporate the different slaves in the project.

With the Siemens environment it is simply done by the IRS slave from the slave list to the Profibus network in the STEP7 programming interface.

According to the GSD:

The type of the slave is: IRPC12-60

The Profibus identification is: 0x0594

The length of users parameters is: 5 bytes but are not used


No extended diagnostic is used

The length of data exchange datagrams is :

- 6 bytes IN (Slave Master)
- 11 bytes OUT (Master Slave)

The slave ID is set using the ID wheels on the main MPU board. Turn off/on the 24 DC supply to reload the new address.

At this point, the Profibus-DP network should be initialised and should work correctly. The master is starting to exchange empty datagrams with the IRS slaves. If this exchange is successful the Profibus LED onto the MPU card turns to green.



6. Start communication by sending commands and receiving data to/from the IRS.

Then the communication is done through simple datagram exchanges between the master and the slaves.

Protocol description and datagram format:

- Input Datagram (S M) (6 bytes)

Command	Reserved.	Vrms		Dead Lamps	
0	1	2	3	4	5

Byte 0: Command byte content:

SCT_D	OVRL	C_OUT	ON/OFF	OVRL	OUT_R	Reserved	
7	6	5	4	3	2	1	0

Bits	Meaning
OUT_R	1 = Notif. "Sector Out of Range" (Sector < 360Vrms) 0 = Normal state.
OVRL	1 = Alarm "Overload" (Electronic Breaker) 0 = Normal state.
ON/OFF	1 = Regulation ON (ON Command acknowledge) 0 = Regulation OFF
C_OUT	1 = Alarm "CutOut" (Breaker) 0 = Normal state.
OVRL	1 = Alarm "OverHeat" 0 = Normal state
SCT_D	1 = Alarm "SectorDefault" 0 = Normal state.

Byte 1: reserved:

This byte is not used.

Byte 2-3: Vrms byte content:

The supply voltage measured by the IRS.

Byte 4 and 5: Dead Lamps bytes content:

1 bit per lamp. The bit is turned to 1 when the IRS detects a load fault

L8	L7	L6	L5	L4	L3	L2	L1	Reserved						L10	L9
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Byte4								Byte5							

- Output datagram (M S) (11 bytes)

Cmd.	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10
0	1	2	3	4	5	6	7	8	9	10

Byte 0 : Command byte content :

Reserved			ON/OFF	Reserved			
7	6	5	4	3	2	1	0

Bits	Meaning
ON/OFF	1 = Regulation ON 0 = Regulation OFF


Byte 1-10: Settings in Percents, to be applied to each channel.

These values should not exceed 100%. If it does, the setting 100% is applied.

Summary: Basic steps to start the regulation:

- Set the desired power for the loads
- Start the regulation.
- Set the power for other lamps or modify the desired power.

LEDs



LED	ON	OFF
(1)	Profibus-DP running	No datagram exchange
(2)	MPU running	MPU error (firmware)
(3)	400 V ON	400 V OFF
(4)	24 VDC on	24 VDC off